



INSTRUCTION FOR 10B601 INDOOR FLOOR PADDING

1. Bottom of floor shoe surface should be clean and dry, remove dirt and loose particles.
2. Peel off backing and place pads on bottom of floor shoe as shown below.

*****CAUTION*****

This goal has been designed to be used for the game of soccer only. Goal posts must be anchored **AT ALL TIMES** and shall be secured against tilting. Do not climb on net or goal framework at anytime! All fastenings must be checked to insure they are fully tightened before and after each use of this product. Goal posts not in use must be disassembled and properly stored in a safe secure area. (See guidelines for Moveable Soccer Goal Safety, included.) Assembled goal posts should not be left unattended. Remove nets when goals are not in use. Do not use this equipment in the threat of high winds. Goal posts should be checked for safety before and after each use. All warning and safety labels included with this product must be visible at all times. Any modification to this or any Kwik Goal product will void any and all warranties.

Parts List

A) Self Adhesive Pads (6)

